Bag for Tent Covers

Large bag for roof covers, side walls and accessories



Bag for covers, walls and accessories

A spacious carrying bag for the roof cover, side walls, pegs and other accessories of your folding tent. It holds covers of all tent sizes.

Size	65 × 40 × 25 cm
Max. load	25 kg
For	roof covers, walls, pegs, accessories
Not for	the tent frame

Package contents

- 1 bag for tent covers

Installation and use

1. **Dry the covers**
   Make sure the roof cover and walls are clean and completely dry.
2. **Fold**
   Fold the covers loosely. Roll PVC windows instead of folding them sharply.
3. **Pack**
   Put the heavier items (pegs, small parts in a separate bag) at the bottom and the covers on top.
4. **Close and carry**
   Close the bag and carry it by both handles.

⚠ Safety instructions

For this product

- The bag is not designed for the tent frame.
- Do not exceed the maximum load of 25 kg.
- Keep the bag away from open fire and heat sources.

General

- Always anchor the tent properly (weights, sand or water bags, pegs or ropes) before use.
- Take the tent and its accessories down before strong wind, storm, heavy rain, snow or hail. Never leave them installed unattended or overnight in bad weather.
- Never let rain water collect on the roof or any fabric part – remove accumulated water immediately and keep all fabric fully tensioned so water runs off.
- Keep children away during installation and do not let them play with the parts.
- Check all parts before every use and replace damaged parts. Use only original BRIMO parts.

Care and storage

- Never store wet covers in the bag – risk of mould.
- Clean the bag with a damp cloth and let it dry.

The manufacturer is not liable for damage caused by wind, rain, snow, accumulated water, insufficient anchoring or by not following these instructions.